2010-2-PAK-NET128

Centrales analógicas: código activación ampliación de la red RS485 - 32 nodos y 128 lazos.

Overview

The fire panel allows for its capabilities to be extended by use of USB dongles. These USB dongles are called PAK, which stands for Panel Activation Key. The use of the PAK will activate additional high-end feature(s) in the panel. Depending on the required functionality, separate and multiple PAKs can be used to enable these functionalities. Functionalities like number of nodes/loops, supported detector protocol, used TCP/IP communication protocol for remote monitoring, communication towards management software like BACNet or Modbus, etc, can be enabled by usage of the PAKs. The PAK is tied to the serial number of the panel, but does not have to stay connected to the panel. It can be removed once the PAK has been installed, and the feature is enabled in the panel. It is therefore recommend that PAKs stays with the panel at all time, for example in case of performing reset functions or re-installations.

Detalles

- Increases panel capacity to 32 nodes & 128 loops network
- Compatible with panel firmware 3.1. or higher

2010-2-PAK-NET128

Centrales analógicas: código activación ampliación de la red RS485 - 32 nodos y 128 lazos.

Especificaciones técnicas

General

Compatibilidad	USB type 2.0

Físico

Factor de forma	Pequeño
Dimensiones físicas	22 x 70 x 5 mm (W x H x D)
Peso neto	75 g
Peso de envío	110 g
Tipo de Montaje	En armario

Medioambiental

Temperatura de funcionamiento	-5 to +40°C
Temperatura de almacenamiento	-20 to +50°C
Humedad relativa	Max. 95% noncondensing

Regulador

Certificación	EN54-13, EN54-2
Normativas	EN54-2 EN54-13
Medioambiental	CPD WEEE RoHS

Last updated on 18 October 2024 - 13:21